

Gen 2 Call Plate

(Dry Area – Latching Version)



Indigo Care's Gen 2 Universal Call Plates are Australian designed and backward compatible to most Nurse Call Systems that conform to AS3811. The Call Plates are a new contemporary design and available with 2 or 3 buttons. The buttons have an aesthetic appeal and a natural depth which make them easier to see. They also have two Jack Inputs allowing for Normally Open (Pendant/Floor Mat) and Normally Closed (Bed/Chair Mat) Nurse Call/Fall Prevention equipment. These Call Plates are designed with the elderly patients in mind as our call points feature large easily identified colour coded buttons that are easy to press. The soft, visually pleasing buttons have a low brightness backlight which makes them visible during the day or night. Once activated by a resident or staff the backlight goes to full brightness and acts as a reassurance light indicating the point is active. The call point can also be activated by using a pendant which easily connects via an optional pendant socket. This call point is designed to interface with Indigo Care's RF devices.

Wiring Diagram is available upon request only.

Part Number:

➤ Latching Switch

MED-GCPV2.(X)

X Denotes:

C/C = CALL/CANCEL

A/C=ASSIST/CANCEL

C/CS = CALL with Jack Socket

A/CS = ASSIST/CANCEL with Jack Socket

E/C = EMERGENCY/CANCEL

A/C/CS = ASSIST/CALL/CANCEL

with Jack Socket

Key Specifications:

- Australian Design
- C-Tick Approved
- IP65 Rating
- Available as 2 or 3 Button
- Anti-Bacterial Button
- Raised & Easy to Press & Clean Buttons
- Available with or without a 6.3 mm Stereo Jack
- Two Jack Inputs: Normally Open (Floor & Pendant), Normally Closed (Bed/Chair)
- Mechanical Tactile Switch Actuator
- Input Supply: +13.8 to 27VDC
- Optional Buttons: Nurse Call – Green, Assist-Yellow, Emergency-Red
- Connectors via RJ45 x 2 and Terminal block
- Configurable to Master & Slave Call Point
- Output: Selectable to Active High or Active Low
- Configurable Pendant Pin Output (Ring, Tip & Shield) via Jumper Link
- Bed Light On-Off Connection on the Main Board
- Optional alarm for Pendant-out
- Suits Standard Australian Electrical Boxes and Mounting Enclosure



INDIGO CARE

(Horizon Electronics Company, T/as)
2/93 Rushdale Street, Knoxfield, VIC, 3180
PH +61 3 9763-2988
www.indigocare.com.au
ABN 36007302801

ORDER INFORMATION
Email your purchase orders to
sales@indigocare.com.au